

Shoring Suite

Version 8

User's Manual



All the information (including technical and engineering data, processes, and results) presented in this program have been prepared according to recognized contracting and/or engineering principles, and are for general information only. If anyone uses this program for any specific applications without an independent competent professional examination or verification of its accuracy, suitability, and applicability by a licensed professional engineer, he/she does so at his/her own risk and assumes any and all liability resulting from such use. In no event shall CivilTech Software be held liable for any damages including lost profits, lost savings, or other incidental or consequential damages resulting from the use of or inability to use the information contained within the program.

Information in this document is subject to change without notice and does not represent a commitment on the part of CivilTech Software. This program is furnished under a license agreement, and the program may be used only in accordance with the terms of agreement. The program may be copied for backup purposes only.

The program or user's manual shall not be reproduced, stored in a retrieval system, or transmitted in any form by any means, electronic, mechanical, photocopying, recording, or otherwise, without prior written consent from CivilTech Software.

Thanks to John J. Peirce, P.E., D.GE of Peirce Engineering, Inc. for his invaluable review and feedback of this manual

Copyright ©2017 CivilTech Software. All rights reserved.

Simultaneously published in the U.S. and Canada.

Printed and bound in the United States of America.

Published by

CivilTech Software

Web Site: <http://www.civiltech.com>

TABLE OF CONTENTS

CHAPTER 1: INTRODUCTION, INSTALLATION AND ACTIVATION	4
<i>Modules</i>	<i>4</i>
<i>Problem and Troubleshooting</i>	<i>4</i>
<i><Preview and Print Screen></i>	<i>4</i>
<i>Installation and Activation</i>	<i>5</i>
CHAPTER 2: GENERAL MODULE	7
<i>Introduction</i>	<i>7</i>
<i>A. General Input Page</i>	<i>7</i>
<i>B. Run Modules in Steps</i>	<i>8</i>
<i>C. User and Firm Page</i>	<i>8</i>
CHAPTER 3 SHORING MODULE.....	9
<i>Introduction</i>	<i>9</i>
<i>Shoring Menu</i>	<i>9</i>
<i>Running the Program</i>	<i>9</i>
<i>Samples</i>	<i>9</i>
<i>A. General Page</i>	<i>9</i>
<i>B. Pressures Page</i>	<i>11</i>
<i>C. Braces and Force Page</i>	<i>13</i>
<i>D. Option Page</i>	<i>15</i>
<i>E. Two Walls Page</i>	<i>17</i>
CHAPTER 4: EARTHPRES MODULE.....	18
<i>Introduction</i>	<i>18</i>
<i>Warning!</i>	<i>18</i>
<i>EarthPres Menu</i>	<i>18</i>
<i>Running the Program</i>	<i>18</i>
<i>Samples</i>	<i>18</i>
<i>A. General Page</i>	<i>18</i>
<i>B. Soils and Water Parameter Page</i>	<i>19</i>
<i><Soil Parameter Screen></i>	<i>20</i>
<i>C. Active Side Page</i>	<i>20</i>
<i>D. Passive Side Page</i>	<i>22</i>
<i>E. Options Page</i>	<i>22</i>
CHAPTER 5: SURCHARGE MODULE.....	24
<i>Introduction</i>	<i>24</i>
<i>Surcharge menu</i>	<i>24</i>
<i>Running the Program</i>	<i>24</i>
<i>Samples</i>	<i>24</i>
<i>A. General Page</i>	<i>24</i>
<i>B. Point Loads Page</i>	<i>25</i>
<i>C. Line Loads Page</i>	<i>26</i>
<i>D. Strip Loads Page</i>	<i>26</i>
<i>E. Area Loads Page</i>	<i>27</i>
<i>F. Infinite Loads</i>	<i>28</i>
<i>G. Railroad Load Page</i>	<i>28</i>
CHAPTER 6: HEAVE MODULE.....	29
<i>Introduction</i>	<i>29</i>

<i>Heave MENU</i>	<i>29</i>
<i>Running Program.....</i>	<i>29</i>
<i>Samples.....</i>	<i>29</i>
<i>A. General Page</i>	<i>30</i>
<i>B. Soils Page.....</i>	<i>30</i>
CHAPTER 7: METHOD FOR SHORING MODULE.....	31
<i>7.1 Terminology.....</i>	<i>31</i>
<i>7.2 Arching.....</i>	<i>31</i>
<i>7.3 Vertical Bearing Capacity.....</i>	<i>32</i>
<i>7.4 Embedment Calculation</i>	<i>33</i>
<i>Users are responsible to have adequate Factor of Safety (F.S.) in embedment based on project condition. There are two ways to apply F.S. in embedment. One is input F.S. in Option page D., Item 15. It will reduce passive pressure by dividing the pressure by F.S. Another way is increasing embedment length or total pile length based on calculated embedment from program.</i>	<i>33</i>
<i>7.5 Limited Penetration in Rock.....</i>	<i>34</i>
<i>7.6 Adding Ms for Embedment Calculation</i>	<i>34</i>
<i>7.7 Normal Brace Level and Low Brace Level. (This option is removed from program due to the risk of instability).....</i>	<i>35</i>
<i>7.8 Deflection Calculation:</i>	<i>35</i>
<i>7.9 Pile Strength and Size.....</i>	<i>37</i>
<i>7.10 Single Span Beam and Continuous Beam</i>	<i>38</i>
<i>7.11 Pile Bulking</i>	<i>38</i>
<i>7.12 Step Wall Calculation.....</i>	<i>39</i>
CHAPTER 8: METHOD FOR THE EARTH PRES MODULE.....	41
<i>8.1 Flexible Wall and Rigid Wall</i>	<i>41</i>
<i>8.2 Ko and Ka Conditions</i>	<i>41</i>
<i>8.3 Apparent Pressure Envelopes.....</i>	<i>41</i>
<i>8.4 Method of Earthquake Analysis.....</i>	<i>43</i>
<i>8.5 Soil Parameter Screen and Relationship.....</i>	<i>44</i>
<i>8.6 Cohesion in Shoring Analysis.....</i>	<i>45</i>
<i>8.7 Earth Pressure Analysis</i>	<i>45</i>
<i>8.8 Numerical Method vs. Equation Method:</i>	<i>48</i>
<i>8.9 Water Table and Seepage.....</i>	<i>48</i>
CHAPTER 9: METHOD FOR SURCHARGE MODULE	50
<i>9.1 Strip Loads (Wayne C. Teng Equation).....</i>	<i>50</i>
<i>9.2 Area Loads</i>	<i>50</i>
<i>9.3 Line Loads</i>	<i>51</i>
<i>9.4 Point Loads.....</i>	<i>51</i>
<i>9.5 Infinite Loads.....</i>	<i>51</i>
<i>9.5 Railroad Loads.....</i>	<i>52</i>
<i>9.6 Flexible and Rigid Walls</i>	<i>52</i>
CHAPTER 10: METHOD FOR HEAVE MODULE	53
<i>10.1 Terzaghi's Method.....</i>	<i>53</i>
<i>10.2 Hard Stratum.....</i>	<i>54</i>
CHAPTER 11 QUESTIONS & ANSWERS	55

Terminology:

[] indicates a button or input item. The number in the brackets corresponds to the item number in the program.

{ } indicates a panel, a screen, or a module.

<> indicates a section in the Chapter 7-10 of the manual.

Z - depth starts from the wall top.

Base -means the excavation base, excavation bottom, or the dredge line.

Embedment – Pile length below the base, also called penetration

CHAPTER 1: INTRODUCTION, INSTALLATION AND ACTIVATION

This manual of Shoring Suite version 8 has two portions: Chapters 1-6 describe how to input data and run the program, and chapters 7-10 describe calculation methods and theories. The program may change frequently, and so will the manual. Please check our web site for the new version (posted by date) of the manual and download it in PDF format. To find the manual, go to the Download Page of our website: <http://www.civiltech.com>.

Modules

The program has 5 modules:

General: Used for software activation and modules arrangement. It is not necessary to input data in General module. This module does not conduct any calculation.

EarthPres: Used for determining active, passive, and earthquake pressure from complicated soil, water, and ground conditions.

Surcharge: Used for determining lateral pressure from the surcharge load on the ground surface, such as line, point, strip, area, and railroad loading.

Shoring: Used for conducting analysis and design for shoring wall. Determining moment, shear, and deflection. Finding pile length, pile size, brace force, and tieback length.

Heave: Used for checking if the shoring system is stable.

- Each module has own files. The files should be saved within the own module. There is no way to save the files from two or three different modules together.
- The units for each module are shown in bottom bar of the module. Most time, kip and ksf are used instead lb, or psf, except unit weight is pcf.
- The top text menu is shared for all modules. When a module is clicked. It is the current module. Then the top menu is only working for this manual

Problem and Troubleshooting

If you encounter any problems, please save your data file and send us an email with the input files for each module. Most time, telephone call cannot solve the problem. **Attached input files and email can solve the problem quickly.**

Email: support@civiltech.com. **Please review Chapter 11, Questions & Answers before contact us.**

If you need administrative assistance such as USB problem, please email your request to sales@civiltech.com

Notes

- In the program, if input item is in **black**, that means the item is important. If input item is **blue**, that means the item is optional.
- If an option is marked with a *, the option is set as the default and is the recommended option.
- Modules share the top pull-down menu. If one module is active, the main menu will be used for that module.
- Each module except the General module has several samples that can be opened by pull-down a list on the right side of the top menu bar. Click [Results] button to run the samples.

<Preview and Print Screen>

Most modules have the Preview and Print Screen when users press the [Results] button. There are buttons at the top of the screen. The function of each button is described below:



Finger Right

Finger Left

View Page Height

View Page Width

Zoom In

Zoom Out

Printer

If there are more than one page, turn to next page

If there are more than one page, turn to previous page

Zoom to the page height

Zoom to the page width

Enlarge the image

Shrink the image

Send to printer

Printer Setup	Set up printer. For some Windows system, this button has no function or removed.
Clipboard	Copy the graphics to Windows Clipboard. Users can paste the graphics into any Windows program, such as MS-Word, Power Point, and Excel.
Save	Saves graphics to a Windows metafile, which can be opened or inserted by other drawing programs for editing.
Close Door	Close Preview

Installation and Activation

The program has two activation methods: USB key activation and code activation. Prior to activation, the program is in demo mode. In demo mode, some functions of the program are disabled. Please follow the installation and activation procedures below that correspond to your version of the software.

USB key:



If you have CivilTech USB key, the program is inside the key. You can run the program from the key...

Introduction of USB key

- Civiltech USB key functions the same way as a USB flash drive, (also called memory sticks or jump drive), but with a special chipset inside. It has a memory of 128 MB, and USB 2.0 connectivity. The key is compatible with Windows 2000, Xp, 7, 8 or higher, but may not work with Windows 98 (You need to install USB driver for Win98).
- Insert the key into any USB port in your computer. If you do not have an extra USB port, you should buy a USB extension cord (about \$10-\$20)
- Wait until the small light on the back of the USB key stops flashing and stays red. This means that Windows has detected the USB key. A small panel may pop up that says "USB mass storage device found", you can either close this panel or click "OK".
- Do not remove the key while the light is blinking, as that will damage the key. You can remove the key only during the following situations:
 1. Your computer is completely turned off, or
 2. You have safely ejected the key from the system. You can do this by going down to the Windows task bar, finding the icon that says "Unplug or Eject Hardware" (usually located at the bottom right-hand side of the screen) and clicking on that. It will then tell you when it is safe to remove the hardware.

Running the Program within the Key.

- No installation is required.
- After you insert the key, use Windows Explorer (or click My Computer) to check the USB drive (on most computers, it is either called D:, E:, or F:). You will find some files inside. There is a folder called "/Keep" inside. Do not change, remove, or delete this folder or the files inside, or else your key will become void.
- You will find a folder called "/Shoring8". Open this folder and find ShoringSuite.exe. Double click this program to run it from your key.
- You can also create a new folder, save and open your project files directly to and from your key. There should be enough room on the key for your files.

Running the Program from your Hard Disk:


- You can also run the program from your hard disk; the program may run a little bit faster from your hard disk.
- There is a file called sh_setup.exe in the root directory of the key. Double-click on the file to start installation.
- The installation process will help you to install the program on your local hard disk. Installation to network drive or disk is not recommended. The program may not work properly.
- The installation will create a shortcut on your desktop. Click the icon to start the program.
- You still need to plug the USB key into the USB port to run the program.

It will automatically detect the USB key.

- The key activation status can be checked from Help in General Module under Activation.

If you do not have USB key:

If you received the program from email or from download...



Installation to Local Hard Disk:

The installation file is called sh_setup.exe. Click it will start up the installation process automatically. The installation process will help you to install the program on your local hard disk and create a shortcut on your desktop. Installation to network drive or disk is not recommended. The program may not work properly.

Temporary Activation before receiving USB key.

- After you have purchased the program and paid for express service we will send you an email to help you to download a full version of program. You need to follow the instruction to open an activation panel.
- The CPU number is shown on the panel. This is a unique number for your computer, which must be reported to CivilTech by email.
- A temporary activation code will be emailed back to you after we verify you have purchased the program.
- Input the activation code in the Activation Pane, and then close the program.
- Start the program, which has full function now. You can open the program for 20 times. You may run many times for each opening.

Download Manual from Internet

The most updated manual can be downloaded from Download page of our Web site (www.civiltech.com/software/download.html). Click on Shoring Suite Manual to open the manual, (you must have Adobe Acrobat Reader to open the file). Then, save the PDF file onto your hard drive. If you have slow internet connection, you should save the file to your hard disk instead of opening it online. To save the file, using the right mouse, click and select [Save Target As].

Quitting the Program

From the File menu of any modules, select [Exit Suite].

Input Firm and User Name

From the Help of General Module, select Firm and User. Once the panel pulls out, enter in your firm's name and the user's name. This information will be printed in the report.

About Program and Version

From the Help of General Module, select About. This will provide you with the version of the program. Click anywhere on the screen to exit back to the program.


Important:

- It is not necessary to input data in General module. This module does not conduct any calculation.
- Each module has own files. The files should be saved within the own module. There is no way to save the files from two or three different modules together.
- The units for each module are shown in bottom bar of the module. Most time, kip and ksf are used instead lb, or psf, except unit weight is pcf.
- The top menu is shared for all modules. When a module is clicked. It is the current module. Then the top menu is working for this manual.

CHAPTER 2: GENERAL MODULE

Introduction

This module manages the appearance of the other four modules. Inputted data in this module can be sent to four modules to save time. It is not necessary to input data in this module. This module does not conduct any calculation.



Pull Down Menus


File: General module cannot open and save files. You need to open and save files in each module.

Help/Help Read the help manual or press F1 to open the help manual.

Help/Troubleshooting: If you encounter any problems, please save your data file and send us an email with the attached data file. We will respond to you as soon as possible. Email: tech@civiltechsoftware.com

Help/Activation: Use this to open {Activation Panel} and to input the activation code. If you have a CivilTech USB key plugged in your computer, you do not need to activate your program.

Help/Users and Firm: Use this to input user and firm data.



A. General Input Page

This module does not do any calculation. The data in this module can be sent to all of the other modules to save time. It is ok not to input data in General Module. You can input data individually in each module.

- [1] Height is from the wall top to the base line (dredge line).
- [2] Select wall type in two groups:
 - Sheet pile group. In this group, [3] and [4] should equal 1.
 - Soldier pile group.
- [3] Pile Diameter: In the Soldier pile group, for diving piles, input the width of the pile flange or diameter, and for drilled shaft, input the diameter of the shaft. For the Sheet pile group, input 1.
- [4] Pile Spacing: For the Soldier pile group, input lagging space. For the Sheet pile group, input 1.
- [5] After inputting and selecting data, press [5] to automatically send data to the other modules.
- [6] You can choose between either English or Metric units. The units chosen are shown on the bottom in each module. Selecting a new unit will clear all the data in all modules.
- [7] This option keeps the {General Module} on top of all the other modules.
- [8] When opening the program, there are cover pages for each module. Check this box to automatically turn off all cover pages the next time the program is opened.

[9] If you do not want to print graphics in color, you can select this option.


Users can arrange and run the modules in two ways:

[A] Users can arrange each module as a separate window and run each module one by one.

[B] Run Modules Steps - Users can run each module in step by step. See Page B

B. Run Modules in Steps

Users can run each module in steps based on input data available. If users already have soil pressures, users can directly input in Shoring without EarthPres.




C. User and Firm Page

Input the user and firm name in the boxes as shown below and press [Save]. The names will be saved by the program and automatically displayed on the reports.

CHAPTER 3 SHORING MODULE

Introduction

{Shoring} requires users to input soil pressures. Based on the pressures, it determines the moment, shear, deflection, pile size, brace reaction and embedment of a shoring system based on DM-7 (U.S. Navy Design Manual), USS (Steel Sheet Piling Design Manual), and FHWA-RD-75 (Federal Highway Design and Construction Summary). The program can be used to analyze and design sheet pile walls, soldier pile walls, and a variety of shoring walls. There are a pull-down menu, menu bar, and total of 5 pages. A description of each item is listed below.



Shoring Menu


At the top of screen, there is pull-down menu. This menu is shared by all the modules, and will change to reflect the active module. Usage of this pull-down menu is as the same as in most Windows software. Here are some specific functions of Shoring menu:

File/Open: V8 can open V6 and 7 files from [Files of Type] list as shown in right Figure. Because V8 adds many new fields, Users need to modify the V6 and V7 before run the program.

Edit: enabled when users clicks one of the tables on Pages B, C, and D. Users can insert, delete, copy, and paste a row of data in the table.

Help/Help: Provides general help on how to use the Shoring module.

Help/General Module: Opens {General} module if it has been closed.



Running the Program

There are three major buttons on the top menu bar. After inputting data or opening a sample, users can press one of these three buttons to run the program:

- [Results] View the graphics and results
- [Report] See text results
- [Diagram] View and print shear, moment, and deflection diagrams.


Samples

Sample files can be opened from the list on top right of menu bar. Samples that start with E are in English (Imperial) units. Those that start with M are in metric units. Users need to switch units in the {General} module to open samples of either English or Metric units.

A. General Page

This page is for general information. **Title 1** is the project title (text only). The {General} module can overwrite this text if the user presses [5. Send data to all modules]. {EarthPres} also will overwrite it when the [Send to Shoring] button is pressed. **Title 2** is the subtitle (text only).

- [1] Height is from the wall top to the base line (dredge line). The {General} module can overwrite the text if the user presses [5. Send data to all modules]
- [2] Select a wall type. Drawings on the right side of the screen indicate the wall types.
- For a Sheet piles, [3. Pile diameter] and [4. Pile spacing] should be equal to 1.
 - For Soldier piles, users can choose between drilled shaft and driving pile. For details, refer to <7.2 Arching>. A sample is shown in the figure. Pile #1 in the figure has two active spacing and two passive spacing.



**Example: For Pile #1
Assume Arching=2**

Active Spacing=S

Active Spacing=0.5S

Active Width=D₁
Passive Width=2D₁

Active Width=D₂
Passive Width=2D₂

General Rule:


Active Spacing=S (above base called spacing)

Active Width=D (below base called width)

Passive Width=2~3D (below base, including arching)

- [3] Pile diameter. For a driven soldier pile, enter flange width. For a drilled-in soldier pile or drilled shaft, enter the diameter of the drill hole. The hole should be back filled with concrete or lean concrete. Some people advocate filling the drilled hole with stone or soil. If so, use the pile flange width. For sheet pile, concrete, slurry wall, and trench box enter 1. English unit: 1 foot; Metric unit: 1 meter.
- [4] Pile spacing. For a soldier pile, enter lagging spacing. For sheet pile, concrete, slurry wall, and trench box enter 1. English unit: 1 foot; Metric unit: 1 meter.
- [5] After inputting data from [1] to [4], press [5] to automatically write data to [6] and [7].
- [6] Depth and spacing for active pressures. Above the base, enter lagging spacing. Below the base, enter pile diameter. No arching should be applied to active spacing. For sheet pile, concrete, slurry wall, and trench box, spacing = 1. English unit: 1 foot; Metric unit: 1 meter.
- [7] Depth and spacing for passive pressures. The depth should start from where the passive pressure starts, most of time it is at the base. The spacing is including passive arching. Enter pile diameter and multiply the passive arching. For details, refer to <7.2 Arching>. For sheet pile, concrete, slurry wall, and trench box, spacing = 1. English unit: 1 foot; Metric unit: 1 meter.

Users can directly input [6] and [7] without press [5] or modify [6],and [7] after pressing [5].



B. Pressures Page

[1][2] Input active and passive pressures in tables: A pressure is a trapezoid polygon that is defined by 2 depths and 2 pressures called Z1, Z2, P1, and P2. A slope is defined as:

$$\text{Slope} = (P2 - P1) / (Z2 - Z1)$$

One trapezoid polygon occupies one row of data in the table. Users have 3 options in [3] to input data.

[3] Select one of the three options in the Input Options box. Users only need to input four values for each pressure. The program can remember the option as default option when the program is closed. When users open the program next time, the option is automatically selected.

- [Input P2 => Slope]: input Z1, P1, Z2, and P2, the program will calculate Slope.
- [Input Slope => P2]: input Z1, P1, Z2, and Slope, the program will calculate P2.
- [Double click on →]: If users input Z1, P1, Z2, and P2, double-clicking on Slope will get the Slope data. If users input Z1, P1, Z2, and Slope, double-clicking on P2 will get the P2 data.
- Users can input comments in a row by typing a * in the 1st column. The rest of the columns are then ignored and can be used for comments or remarks. Each input cell can only hold 5 characters.

Input Option 1:

Input Z1, P1, Z2, and P2. The program calculates Slope.

Input Option 2:

Input Z1, P1, Z2, and Slope. The program calculates P2.


Input Option 3:

Input Z1, P1, Z2, and Slope, then double click P2.

Input Z1, P1, Z2, and P2, then double click Slope.

Notes:

- Z2 must > Z1
- Input 800 or 999 for unknown depth of Z2 (by double click)
- Negative pressure is allowed, represented in the diagram by red.
- Negative Z1 is allowed if it is above a wall top.
- Double-clicking Z1 or P1 of the next row will copy the Z2 and P2 from the previous row.



- [4] Corner pile: Corner soldier piles only need to support a half of active lagging spacing above base. But they need to support active pressure with full width of shaft below base. They also have full passive spacing including arching. However, the passive spacing can't be more than active spacing above base. The program will check the spacing and give 50% reduction of active pressure above base. Sometime, a corner pile can have a smaller size and less embedment. In some cases, corner pile can be replaced by a steel angle.

Notes:

- Active pressure can be above ground (negative Z1). Passive pressure can be above the base line.
- Check the depth of active spacing in [6] of Page A. It should be above or equal to the depth of any active pressures. It is the same for the passive spacing in [7] of Page A. For example, if the depth of the first passive spacing starts with 10 feet, and the user inputs a passive pressure of Z1=-9 feet, the program cannot determine the spacing for the passive pressure.
- If users do not know Z2, enter 800 or 999 for an unknown Z2. Double click the Z2 column can get 800.
- If the 2nd pressure is a continuo of the 1st pressure, users can double-click Z1 or P1 on the 2nd row. It will copy Z2 and P2 from the 1st row.
- A negative value of P1 or P2 can be inputted. If we assume the wall is on right side and excavation is on left, a negative active pressure means it is from left to right. A negative passive pressure means the pressure is from the right to the left. If any one of P1 or P2 is negative, the graphics will be shown in red.
- For water pressure and if there is seepage at wall tip, the water pressure at wall tip is zero. Since the depth of wall tip is unknown, users can input Z2=Tip, P2=0, Slope=to tip. If Earthpres module is used, these values will be automatically generated and exported to Shoring module.
- **If the graphics show red color in pressure diagram, you may have negative value in pressure input.**
- **Any passive pressures above excavation base is ignored by the program.**

EXP01.SH8 - Shoring

File Edit Print View Results Report Diagram Help

E01. Cantilever: Sheet pile

A. General B. Pressures C. Braces and Force D. Options E. Two Walls

1. Active, Water, Surcharge Pressures (above and below base)

Load Factor (Multiplier) 1.0

Z1 top	P1 top	Z2 bot.	=> P2 bot.	Slope
0	0	12	0.408	0.034
*	Below	Base		
12	0.408	100	3.400	0.034

2. Passive Pressures (below base)

Factor of Safety (Divider) 1.0

Z1 top	P1 top	Z2 bot.	=> P2 bot.	Slope
12	0	100	49.28	0.56


3. Input Options:

☐ Input P2 => Slope ☒ Input Slope => P2 ☐ Double Click on >

4. Corner Pile with Half Active Spacing ?


DEPTH: ft, PRESSURE/FRICTION/BEARING: ksf, SLOPE: kcf, FORCE: kip, MOMENT: kip-ft, DEFLECTION: in, I: in4, E: ksi

- [2] No-load zone calculation: the tieback, deadman, and plate anchor should be located outside of the no-load zone. Press [Auto] to get the recommended value. Press [Help] for a definition of the no-load zone.




Wale

Strut and Raker



Deadman



Tieback





Plate Anchor

Chance anchor, Screwed, Plate or Helix.



Sheet Pile as Anchor

Brace Spacing: the horizontal distance between two braces. It may or may not equal to pile spacing. Brace Spacing = 1 for Wale and Continuous Brace

Numbers show in (...) are for Examples

Passive Slope=Eqv. Density=Kp*G
G = Soil unit weight

- [3] Top brace is increased by 15%. The top brace in a multiple bracing system should be increased by 15% due to unexpected surcharge at surface and over excavation for 2nd brace. (Ref. DM7.2-103). This option should only be used in the case of two or more bracing levels.
- [4] External force: see [Help] for details. This table lets users input concentrated loads on the wall. Users also can input vertical loads on top of the wall (see Sample E11).
- Angle: clockwise is positive.
 - Force: Pushing on the wall is negative; pulling on the wall is positive. This is colored red in the graphics.
 - Spacing is the horizontal distance between two forces.
 - For external pressures, input active pressure on Page B.

UNTITLED - Shoring

Select samples below: (E-English; M-Metric)

A. General | B. Pressures | C. Braces and Force | **D. Options** | E. Two Walls

1. Type of Lateral Support (Braces)

☐ 1. No ☐ 4. Plate Anchor ☐ 7. Sheet Pile

☐ 2. Strut, Raker ☐ 5. Deadman

☒ 3. Tieback ☐ 6. Mixed

2. No-Load Zone

V-Line: 10
Angle2 from H. Line: 60
H-Line (Input H/V ratio): 0.25

3. Top Brace Increase (Multiple Braces)

☒ Add 15% ☐ No


4. External Force (Against Wall - Negative)

Z (depth)	Force	Angle	Spacing

*For Tieback: Input1 = Diameter; Input2 = Bond Strength

Bond Strength, Pressure: ksf or kPa, Diameter, Width: ft or m, Passive Slope: kcf or kN/m3

DEPTH: ft, PRESSURE/FRICTION/BEARING: ksf, SLOPE: kcf, FORCE: kip, MOMENT: kip-ft, DEFLECTION: in, l: in4, E: ksi



- Spacing is the horizontal distance between forces.
- If the force is pushing against the wall, input a negative value.
- If the force is pulling on the wall, input a positive value.

D. Option Page

- [1] Pile size selection has three options.
 1. No selection of pile in results.
 2. Group of piles that meet moment capacity (these are listed after clicking [Results] as well as in the pull-down list [2]).
 3. Select user inputted pile specified in an adjacent box

To let program to select pile size, these steps should be performed:

- Step 1. Select option 2.
- Step 2. Press [Results] to the program. After this finishes, [2] will be filled with available piles.
- Step 3. Open step [2] to select a pile. The selected pile will also be displayed adjacent to option 3 of [1]

External Force

EXP10.SH8 - Shoring

Select samples below: (E-English; M-Metric)

A. General | B. Pressures | C. Braces and Force | **D. Options** | E. Two Walls

1. Pile Size Selections

☐ 1. No Selection and Deflection

☒ 2. List of Suitable Piles **Go!**

☐ 3. User Input Pile: W10x88

☐ 4. User Input I in item 4

9. Embedment Options

☐ 1. Yes ☐ 2. No ☒ 3. Fixed

10. Fixed Embedment =

11. Friction at Pile Tip

☒ No ☐ Unlimited ☐ Limited

12. Add Ms for Embedment

Allowable Moment, Ms = 195.03 kip-ft/foot

13. Check Vertical Bearing Capacity

14. Vertical Bearing Capacity

Side Friction **Help**

Tip Bearing **Help**

15. Factor of Safety moves to Page B.

☒ 16. As Continuous Span Beam **Help**

17. Results Graphics Scale

☒ 1* ☐ 0.75 ☐ 0.5 ☐ 0.25

☒ 18. Deflection Calculation

☒ 19. Show Input Data in Results

☒ 20. Show Diagram Data in Report

21. Cantilever Embedment 1.2 **Help**

☐ 22. Net Pressure x Spacing in Diagram

☐ 23. Ignore Pressures above Wall Top

24. Edit Sheet Pile List

25. Edit Soldier Pile List

DEPTH: ft, PRESSURE/FRICTION/BEARING: ksf, SLOPE: kcf, FORCE: kip, MOMENT: kip-ft, DEFLECTION: in, l: in4, E: ksi

- [2] Pull-down list of piles: users must select option 2 in [1] and run the program to get the list.
- [3] If users selected option 3 of [1] and entered pile name in the adjacent box, pressing [3] fills pile data in I [4] and Ms [12].
- [4] I is Moment of Inertia: Units are in4 in English or 100cm4 in Metric. For example, if I=500cm4, users should input 5 in the box. If the user selects options 3 in step [1], the data will be automatically entered from pile database. For soldier pile, it is per pile. For sheet pile, it is per foot (English) or meter (Metric).
- [5] Use the pull-down menu to select Elastic Module, E. E will be automatically entered to [6].

- [6] Users can modify E after selecting [5].
- [7] Select yield strength, F_y , for steel pile. If the last line "User Input in Item 8" is selected, then input F_b in Item 7. If you use aluminum or wood, you can select "User Input in Item 8", then directly input F_b in [8].
- [8] Input ratio of F_b/F_y : F_b is the allowable bending strength. $\text{Ratio} = F_b/F_y$. Therefore, F_b can be calculated by $F_b = \text{Ratio} * F_y$. Please refer to <7.9 Pile Size and Strength>. If you "User Input in Item 8", then directly input F_b in [8].
- [9] Embedment Options:
- Choose 'Yes' for regular shoring. The program will determine embedment to meet equilibrium requirements.
 - Choose 'No' for a no-embedment system such as a trench box or internal braces. The system must have at least two or more braces.
 - If the user has an existing wall or fixed pile length, choose 'Fixed'. The user needs to input the fixed embedment in [10]. Please note, it is not total pile length. It is pile embedment. <7.4 Fixed Embedment>.
- [10] Enter fixed embedment. Please note, this is not total pile length; it is the pile embedment.
- [11] Friction at pile tip: If bedrock is encountered and pile embedment is limited, there may be friction between pile and rock. Adequate penetration in rock is required to develop friction. Refer to <7.5 Limited Penetration in Rock>.
- Driving steel pile requirement: At least 2-3" penetration in rock
 - Drilled shaft requirement: At least 1' penetration in rock
- Based on the penetration in to the bedrock, following options should be selected.
- If it does not meet the requirements, select [No]
 - If it is strong rock and meets the requirements, select [Unlimited]
 - If it is weak rock and meets the requirements, select [Limited] and input rock strength in the input box. The rock strength is in ksf or kPa.
- [12] During embedment calculation, M_s can be considered as resistance to reduce the embedment. M_s is the allowable capacity for movement in the pile. At least a 5' (1.5m) embedment is needed to develop M_s . (Ref. DM7.2-103). Refer to <7.6 M_s >. M_s will automatically be entered if the user selects option 1 or 2 in step [1]. For soldier pile, it is per pile. For sheet pile, it is per foot (English) or meter (Metric).
- [13][14] Check [13] then input vertical friction and Tip bearing capacity. Refer to <7.3 Vertical bearing> for details.
- [15] Input F.S for passive pressures. If the input pressures are allowable, use $F.S. \geq 1$. If the pressures are imported from EarthPres and the soil parameters (friction and cohesion) in EarthPres are allowable, the pressures are allowable. If the soil parameters or input pressure are ultimate, $F.S. \geq 1.5$ is recommended. The inputted passive pressures are divided by F.S. during calculation. It is moved to Page B, Item 2.
- [16] Marking [16] can reduce the Maximum moment in the pile. Refer to <7.10. Beam Span>.
- [17] The graphics scale in [Results] and [Diagram]. After opening any sample, users can try it out by changing it and pressing [Results]. Turn on or off the Deflection diagram in [Diagram]
- [18] Turn on and off the top deflection in [Results]. The top deflection is shown in () followed pile each name, when option 2 of [1] is selected.
- [19] Turn on or off the input data in [Report].
- [20] Turn on or off the Shear, Moment, and Deflection vs. Depth in [Report], which is a long list.
- [21] For cantilever wall only, the calculated embedment is increased by 20% to reach the design depth in the program. Advanced user may modify this data. It does not affect braced wall.
- [22] [Diagram] button can show two options: 1. Pressure on the wall (ksf or kPa) or 2. Pressure x Spacing on wall (kip/ft or kN/m). Check [22] to get 2nd option, which gives real loading for soldier piles. For sheet pile, these two options are the same.
- [23] Negative depth ($Z < 0$) of a pressure means the pressure is above wall top ($Z = 0$). Check [23] will ignore any pressures above wall top. Uncheck [23] will include the pressures above wall top, which usually present lateral loading on railing, fence or pile head above ground.
- [24][25] Users can open MS-Excel to edit the pile list data. The instructions are shown on top of the Excel file. If you do not have Excel installed in your computer, this function cannot be activated.

Notes:

Users can directly find two database files. One is for Sheet pile and is named: SheetPile8.txt. The other is for soldier pile and is: SoldierPile8.TXT. The two files are in the Shoring8 folder.

E. Two Walls Page

This page is for calculating two stepped walls. For three or more walls, users can analyze the top two walls first, and then continue in this manner for the rest of the walls. Refer to <7.12 Step Wall>.

- The instructions are shown on the top of the page in red.
- The data for Wall 1 and Wall 2 is automatically saved as files F1 and F2. Clicking [F1] or [F2] can retrieve the file and rerun the analysis.
- To see an example, please open example E19 and click on Step 1 and open the example file E20 and click on Step 2.

EXP10.SH8 - Shoring

Results Report Diagram M19. Two Walls, Wall 1 input file (work w/ M20)

A. General B. Pressures C. Braces and Force D. Options E. Two Walls

Instruction: Input Wall 1 data or open file F1. Press [Step 1]

Two Wall Horizontal Distance, X= 100
Two Wall Vertical Distance, Y= 10

Step 1. Run Wall 1 [F1]

H1= D1=

Step 2. Run Wall 2 [F2]

H2= D2=


Xc= Impact Ratio=

Step 3. Add Impact to Wall 2

Step 4. Run Wall 2 with Impact

Warning...

Two Walls Analysis



Wall 1 Impacts To Wall 2

$X_c = 0.6 (H_2 + D_2) + 1.7 D_1$
Impact Ratio: $1 - X/X_c$.
If $X > X_c$, there is no impact.

DEPTH: ft, PRESSURE/FRICTION/BEARING: ksf, SLOPE: kcf, FORCE: kip, MOMENT: kip-ft, DEFLECTION: in, I: in⁴, E: ksi

CHAPTER 4: EARTHPRES MODULE

Introduction

{EarthPres} determines the lateral earth pressures and hydrostatic water pressure on retaining structures. The program can calculate active, passive, hydrostatic water pressure, and earthquake pressures from a set of complicated surface conditions. The results can be integrated into the {Shoring} module for shoring wall designs.

Warning!

It is strongly recommended that the user only use the friction angle to calculate soil pressures. Cohesion is not reliable in shoring design. Using clay materials with zero friction and large cohesion in the program will lead to incorrect results. Refer to <8.6 Cohesion in Shoring Analysis>.


EarthPres Menu

At the top of screen, there is pull-down menu. This menu is shared by all the modules, and will change to reflect the active module. Usage of this pull-down menu is as the same as in most Windows software. Here are some specific functions of EarthPres menu:

Edit: enabled when users click one of the tables on Pages B, C, and D. Users can insert, delete, copy, and paste a row of data in table.

Help/Help: Provides general help on how to use the EarthPres module.

Help/General Module: Opens {General} module if it has been closed.



Running the Program

There are three major buttons on the top menu bar. After inputting data or opening a sample, users can press one of these three buttons to run the program:


- [View] View the graphics but cannot print.
- [Results] View and print the results and graphics.
- [Report] See text results.
- [Shoring] Export results to the {Shoring} module.

Samples

Sample files can be opened from the list on top right of menu bar. Samples that start with E are in English (Imperial) units. Those that start with M are in metric units. Users need to switch units in the {General} module to open samples of either English or Metric units.

A. General Page

This page is for general information. **General Title** is the project title (text only). The {General} module can overwrite this text if the user presses [5. Send data to all modules]. **EarthPres Title** is the subtitle (text only).



- [1] Height is from the wall top to the base line (dredge line). The {General} module will overwrite the text if the user presses [5. Send data to all modules]
- [2] Apparent pressure envelopes are the simplified pressures for shoring analysis. Refer to <8.3 Apparent Pressure Envelopes >
 - 1. The pressures that are calculated directly from the analysis. Some people like to use this option instead of option 2 below (Triangle envelope).
 - 2. Triangle envelope: For no-braced wall with any soil type. Some people also use it for one-braced wall.
 - 3-5. For one or more braced wall. The envelope is based on different soil types. If you know the soil type, select this choice. Otherwise select option 5.
 - 6. For braced walls, it will automatically determine the pressure envelope based on the majority soil types.
- [3] Ka and Ko conditions are based on whether the wall has movement. Refer to <8.1 and 8.2 Ko and Ka Conditions >.
- [4] Options for generation Earthquake loads; refer to <8.4 Earthquake Analysis >.
- [5,6] Input Kh and Kv; usually Kv=0.5Kh, or zero. Refer to <8.4 Earthquake Analysis >.

B. Soils and Water Parameter Page

- [1] A table for inputting soil parameters. Users must click the button [Click to Define Soil] to open the {Soil Parameter Screen} screen, and then input the data. Directly typing the data into the table will result in missing information. However, you can edit the data in the table after closing {Soil Parameter Screen} screen.
- [2] Options for water table and seepage; refer to <8.9 Water Table and Seepage >.
- [3] Water density, typically 62.4 pcf or 9.8 kN/m³
- [4] Usually, if users click File/New, all data in the program will be cleared. Specifying this option will keep the soil data in table [1] for new files.

Warning about Cohesion:

It is strongly recommended to only input friction for soil strength. Cohesion is not reliable in shoring. Inputting cohesion may lead to incorrect results! Refer to <8.6 Cohesion in Shoring Analysis>. If you still want to use C, manual calculate the pressures and directly input in Shoring Module.

<Soil Parameter Screen>

Click the buttons in the 1st column of Soil Table in Page B to open the {Soil Parameter Screen} screen. Then, follow the steps below. For the relationships between the parameters, refer to <8.5 Soil Parameter Screen and Relationship>

1. Select soil type. For clay and silt, select type of Eqv. Clay. It is more suitable for shoring design.
2. Type soil description.
3. Move N1 (spt) to obtain the other parameters.
4. Slightly modify other parameter by moving individual bars.
5. Press [Apply] to close the screen.
6. Edit the data on the table in Page B as you wish.

Notes:

- Eqv. Clay - Equivalent Clay. It is strongly recommend using friction for shoring design; Cohesion is not reliable in shoring. If the soils are clay or silt, select Equivalent Clay as soil type. This type soil converts cohesion to equivalent friction based on N1(spt). Refer to <8.6 Cohesion in Shoring Analysis>.
- N1(spt) – Corrected standard penetration test (SPT) in field. If you do not have N1, use SPT.
- CPT – Cone penetration test in field. If qc is available, users can move N(spt) until CPT=qc.
- The other parameters will change with N (spt). If you know one parameter, such as friction, you can move N (spt) until the friction reaches the desired value.
- G is the total moist unit weight. G_s is the saturated unit weight. G_s will be equal to or larger than G.
- Friction – internal friction angle (phi)
- C – Cohesion of soil
- English unit is on left side. Metric unit is on right side.
- If you want to move N1 without changing other parameters, uncheck the Link Box on right side.

C. Active Side Page


This page is for inputting soil and water lines.


- [1] Input a series of ground lines on the table. Users have to select a soil number for this line. The soil number is defined on Page B. It is assumed that the defined soil is under this line. Users need to input one row per each ground line.
- Select soil number and type by clicking the button in the first column.
- Z is depth from the top of the wall. Negative means it is above the wall.
- X_a starts from wall to the right - Active Side.
- X_a, must = 0 at the starting point of the line.
- X_a, must = 800 or larger at the ending point of the line.

- At end point, double click Xa to get 800
 - Two ground lines cannot intersect.
 - The [View] button provides an instant view of your inputted ground lines.
- [2] Input one water line for the active side. The water line can be above the ground surface or above the wall top

Water Line		10	0	5	56	0	200	0	800
Soil No. and Type	Z	Xa	Z	Xa	Z	Xa	Z	Xa	Z
5. Loose Sand	0	0	10	-6	15	-6	25	-4	28
1. Med. Sand	25	0	23	25	24	60	15	800	
5. Loose Sand	35	0	37	40	30	80	20	800	

- One row per ground line.
- Select one Soil Type under each line.
- Z is depth from the top of the wall. Negative means it is above the wall.
- Xa starts from wall to the right - Active Side.
- Xp starts from wall to the left - Passive Side.
- Xa, Xp must = 0 at the starting point of the line.
- Xa, Xp must = 800 at the ending point of the line. (Double click to get 800)
- Water line can be above ground surface or above the wall top.





D. Passive Side Page

- This page is the same as [C. Active Side Page] above except that Xp starts from wall to the left at the Passive Side.

E. Options Page

- [1] Select from three calculation methods refer to <8.7 and 8.8 Earth Pressure Analysis>
 - Wedge analysis is the default choice
 - Log spiral analysis
 - Coulomb's Equations have limitations and may not work for stepped slop, or a slope angle larger than the friction angle of the topsoil.
- [2] Select from wall friction options (refer to <8.7 Earth Pressure Analysis>)
 - Option 1 is conservative.
 - If the wall is a soldier pile wall, option 2 should be selected.
 - If the wall is a sheet pile wall, option 3 can be selected (Only for Formulary Solution).
- [3] Input the friction in degrees. It is limited to 15 degree.
- [4-7] A factor is multiplied to output pressures. Factor larger than one increase the output pressure. Factor less than one decrease the output pressure. The recommended value is 1. Please note: In Shoring module, there is also a Factor of Safety in Option Page D, Item 15. The F.S. is only applied to passive pressure as item [5] here. However, [5] is multiplied to passive pressure. F.S. in Shoring is divided to passive pressure.
- [8] Because the soil at the base line is distributed during excavation, the upper two feet of passive pressure is commonly ignored in engineering practice. If the top of the excavation base is filled with concrete, users can input zero here.
- [9] The pressures of option 1 of [2] on Page A are converted to apparent envelopes using one of two conversion options:
 - The default conversion factors, which are based on Terzaghi and Peck.
 - Use- input conversion ratio. If this is chosen, items [10-12] must be specified.
- [10-12] Refer to <8.3 Apparent Pressure Envelopes>
- [13] Maximum height of wall shown in graphics (not for analysis): the software will always output enough depth for shoring design. This option only affects the schematics displayed in the [Results]

- [14] Turn on or off the input data in the [Report]
- [15] This option can show the failure lines on the graphical diagrams. This is only available for wedge analysis (Option 1 of [1]).

The screenshot displays the 'EarthPres' software window with the 'Options' tab selected. The interface includes a menu bar with 'Results', 'Report', and 'Shoring' options. Below the menu bar, there are tabs for 'A. General', 'B. Soils and Water', 'C. Active Side', 'D. Passive Side', and 'E. Options'. The 'Options' tab contains several settings:

- 1. Calculation Methods:** Radio buttons for '1.* Numerical Solution (Wedge Analysis)' (selected), '2. Numerical Solution (Log Spiral Analysis)', and '3. Formulary Solution (Coulomb Equation)'.
- 2. Wall Friction Options:** Radio buttons for '1.* No wall friction' (selected) and '2. Active only'. A note states: '* Passive wall friction is only for Formulary Solution'.
- 3. Wall Friction Angle:** A text box containing '30'.
- 4. Factor (Multiplier) of Active Pressure:** A text box containing '1'.
- 5. Factor (Multiplier) of Passive Pressure:** A text box containing '1'.
- 6. Factor (Multiplier) of Water Pressure:** A text box containing '1'.
- 7. Factor (Multiplier) of Earthq. Pressure:** A text box containing '1'.
- 8. Neglect Top Depth in Passive:** A text box containing '0'.
- 9. Apparent Envelope Conversion Options:** Radio buttons for '1.* Default (Terzaghi and Peck)*' and '2. User Input Ratio and Shape below:' (selected).
- 10. Conversion Ratio:** A text box containing '1'.
- 11. Trapezoid Top Shape (<1):** A text box containing '0.25'.
- 12. Trapezoid Bottom Shape (<1):** A text box containing '0.25'.
- 13. Max. Height in Graphics:** A dropdown menu showing 'Very Shallow: 2H'.
- 14. Show Input Data in Report and Results:** A checked checkbox.
- 15. Show Failure lines in Graphics:** An unchecked checkbox.

At the bottom of the window, a status bar displays the following units: 'DEPTH/DISTANCE: ft, UNIT WEIGHT: pcf, FORCE: kip/ft, PRESSURE: ksf, SLOPE: kcf'.

CHAPTER 5: SURCHARGE MODULE

Introduction


{Surcharge} calculates the lateral pressures on retaining structures due to surcharge loads. The results can be integrated into the {Shoring} module for shoring wall designs. This program is based on Boussinesq's equation modified by Teng (USS Design Manual and NAVY DM7).

Surcharge menu

At the top of screen, there is pull-down menu. This menu is shared by all the modules, and will change to reflect the active module. Usage of this pull-down menu is as the same as in most Windows software. Here are some specific functions of Surcharge menu:

Help/Help: Provides general help on how to use the Surcharge module.

Help/General Module: Opens {General} module if it has been closed.



Running the Program

There are three major buttons on the top menu bar. After inputting data or opening a sample, users can press one of these three buttons to run the program:

[Results] View the results and graphics.

[Report] See text results.

[Shoring] Export results to the {Shoring} module.

Users have two options for sending the data to {Shoring}:

- Combine all loads together and send the data to {Shoring} at one time. Only one surcharge pressure is sent to {Shoring}.
- Input each load individually and click [Send to Shoring] several times. Shoring will receive several surcharge pressures and show several surcharge pressures on the diagrams.

Samples

Sample files can be opened from the list on top right of menu bar. Samples that start with E are in English (Imperial) units. Those that start with M are in metric units. Users need to switch units in the {General} module to open samples of either English or Metric units.

A. General Page

This page is for general information. **General Title** is the project title (text only). The {General} module can overwrite this text if the user presses [5. Send data to all modules]. **Surcharge Title** is the subtitle (text only).

- [1] Height is from the wall top to the base line (dredge line). The {General} module will overwrite the text if the user presses [5. Send data to all modules]
- [2] Depth of surcharge: input a positive number if the surcharge load is below the wall top, negative if it is above the wall top

EXP01.LP8 - Surcharge

Select samples below: (E-English; M-Metric)

A. General | B. Point Loads | C. Line Loads | D. Strip Loads | E. Area Loads | F. Infinite Loads | G. Railroad Loads

General Title
E01. Point Load, Page 2, Q=50 kip

Surcharge Title
5' from wall, 1' off center

1. Height of Wall (H) 20

2. Depth of Loads (D) 0

3. Wall Condition

☒ 1. Flexible Wall (Allow wall movement)

☐ 2. Semi-flexible Wall (Some movement)

☐ 3. Rigid Wall (Recommend)

The pressures of flexible wall are 50% of rigid wall.
It is based on shoring practices.
There is no reference. (See manual for details).

4. Load Factor for Surcharge 1

1. Flexible Wall: Wall is flexible such as shoring wall
2. Semi-flexible Wall: Small movement allowed such as retaining wall
3. Rigid Wall: No movement allowed such as basement wall

D: Depth of Loads
+: below wall top
-: above wall Top

LENGTH/DEPTH: ft, Qpoint: kip, Qline: kip/ft, Qstrip/Qarea/PRESSURE: ksf

- [3] Wall Condition; refer to <8.1 Flexible Wall and Rigid Wall> and <9.6 Flexible Wall and Rigid Wall>.
- A flexible wall experiences less pressure because the pressure is released after the walls movement. The calculated surcharge pressure of flexible wall is about 0.5 of the rigid wall.
 - A semi-flexible wall is between flexible and rigid, a small amount movement is allowed. The calculated surcharge pressure of flexible wall is about 0.75 of the rigid wall.
 - A rigid wall experiences more pressure. If the movement is restricted by utilities and sensitive structures behind the wall, this option is recommended.
- [4] Load factor for surcharge: Output pressure will be multiplied by this factor
- If the surcharge is footing, input the load factor for a dead load
 - If the surcharge is traffic, storage or construction loading, input the load factor for a live load
 - If there are two loads, one is considered as a dead load and another is a live load, then the program needs to be run twice and [Send to Shoring] needs to be pressed twice to use the different load factors.


B. Point Loads Page

X Horizontal distance (perpendicular to wall) from the wall to the point load (feet or meters)

Y Horizontal distance from the point load to the section of wall, where the pressure is calculated (feet or meters). It is parallel to wall.

Qpoint Point load in kip/ft or kN/m

Please refer to <9.1 Point Load>




C. Line Loads Page

X Horizontal distance from the line load to the wall (feet or meters).

Qline Line load in kip/ft or kN/m

Please refer to <9.2 Line Load>




D. Strip Loads Page

X Horizontal distance from the edge of strip load to the wall (feet or meters).

Width Width of the load applied (feet or meters).

Qstrip Strip load in ksf or kPa

If the strip pressure is not uniform, then the pressure can be bricked in to several uniform pressures as shown in the figure as well as sample E03. Please refer to <9.3 Strip Load>



E. Area Loads Page


X Horizontal distance from edge of the area load to the wall (feet or meters.)

Width Width of the area load (feet or meters.)

Length Length of the area load (feet or meters.)

Qarea Area load in ksf or kPa

Please refer to <9.4 Area Load>



F. Infinite Loads

The infinite loading has two options:

1. Conversional active or at-rest method. It is based on active failure analysis. This option 1 is recommended.

$p = K_a q$ as active pressure. It is for flexible wall

$p = K_o q$ as at-rest pressure. It is for rigid wall

$p = (K_a + K_o) q / 2$ It is for semi-rigid wall


2. Strip loading method as described in Section 9.1, where Loading Width = infinity.

This option gives much higher pressure. Because it is originally from an elastic solution, even modified by Dr. Teng.

G. Railroad Load Page

The railroad load is for a standard E-60 and E-80 Cooper loading. X is from the wall to the center of the railroad. This value is for a train with a locomotive weight of 520 metric tons and axle load equal to 37 metric tons. Please refer to <9.5 Railroad Load>

Note: For standard E-60 and E-80, A rigid wall option should be selected in Item 3, Wall Condition in General Page A.



CHAPTER 6: HEAVE MODULE

Introduction

If the ground is soft or loose, an excavation may become unstable as a result of heaving at the base. {Heave} determines the stability of the excavation. The program utilizes Terzaghi's method to check the heave condition of a deep cut in soft or loose ground. Please refer to <10.1 Terzaghi's Method >

Heave MENU

At the top of screen, there is pull-down menu. This menu is shared by all the modules, and will change to reflect the active module. Usage of this pull-down menu is as the same as in most Windows software. Here are some specific functions of Heave menu:

Help/Help: Provides general help on how to use the Heave module.

Help/General Module: Opens {General} module if it has been closed.



Running Program


There are three major buttons on the top menu bar. After inputting data or opening a sample, users can press one of these three buttons to run the program:

[Results] View the results and graphics.

[Report] See text results.

Samples

Sample files can be opened from the list on top right of menu bar. Samples that start with E are in English (Imperial) units. Those that start with M are in metric units. Users need to switch units in the {General} module to open samples of either English or Metric units.



A. General Page

This page is for general information. **General Title** is the project title (text only). The {General} module can overwrite this text if the user presses [5. Send data to all modules]. **Heave Title** is the subtitle (text only).

- [[1] Height is from the wall top to the base line (dredge line). The {General} module will overwrite the text if the user presses [5. Send data to all modules]
- [2][3] Width and length of the excavation trench in feet or meters
- [4] Water tables outside and inside in feet or meters
- [5] Outside and inside surcharge pressures in ksf or kPa

B. Soils Page

- [1] Soil layer input:
 - Depth: The depth of each soil layer. The depth is measured from the surface to the top of the soil layer. The topsoil has a depth of zero.
 - Friction: The friction angle of soil in degrees.
 - Cohesion: The cohesion of soil in ksf or kPa.
 - U. Weight: The unit weight of soil in pcf or N/ m3. Please note that the total weight should be used instead of buoyant weight even below water table.
- [2] Bearing Soil: the soil(s) deposited from the excavation base to the depth of B (width of the trench). If there are several soil types found within this range, then an average value of the each soil property should be entered in each respective input box.
- [3] Depth of Hard Stratum: input the depth of hard stratum, which provides support against heave. If hard stratum is encountered within the possible failure zone, the failure surface will be terminated at the top of the hard stratum. Smaller failure zones will generate a higher F.S. Please refer to <10.2 Hard Stratum>.

EXP01.HV8 - Heave

Results Report

E01. Three Soils, w/o Hard Stratum

A. General B. Soils


1. Soil Layers (Depth from Surface)

Depth	Friction	Cohesion	U. Weight
0	0	0.5	130
12	32	0.1	120
25	15	0.15	110

Friction Cohesion Unit Weight

2. Bearing Soil 30 0.150 110

3. Depth of Hard Stratum from Surface



DEPTH/DISTANCE: ft, UNIT WEIGHT: pcf, COHESION/BEARING/PRESSURE: ksf, FORCE: kip/ft

CHAPTER 7: METHOD FOR SHORING MODULE

7.1 Terminology

Base – Excavation bottom or base, also called dredge line

Depth – Starts from wall top, distance above the wall is negative

Embedment – Pile length below the base, also called penetration

7.2 Arching

Arching effects are commonly applied in soil-structural interactions when the loads transfer from soil to structure or vice versa. The rigid point receives more loads and the softer point receives fewer loads. Arching effects apply to {Shoring} in three ways:

Horizontal Arching for lagging calculation: because the soldier pile is rigid and the timber lagging is flexible, the uniformly distributed pressure is redistributed and reduced in the center span due to horizontal arching. This will be handled in our lagging module. This arching does not apply to sheet pile walls.

Vertical Arching for apparent pressure envelopes: in a braced wall, the soil pressure increases at the brace location and reduces mid-span between braces due to vertical arching. The redistributed pressures are called apparent pressure envelopes. This is handled in the {EarthPres} module. Please see the {EarthPres} section of the manual for more details. This arching does not apply to cantilever walls or one braced wall. Refer to <8.3 Apparent Pressure Envelopes>.

Passive Arching for passive spacing below the base: when the soldier pile is pushed by active pressure and loading, passive resistance is developed to counter the movement of pile. Thus a large area of the soil is mobilized. The effective width is about one to three times the width of the shaft. For sheet piles, there is no arching, so the passive arching spacing is 1. The following is the equation for passive arching spacing for soldier piles:

$$\text{Passive Arching Spacing} = \text{Arching} * D * n$$

Where:


D is the pile size. For drilled shaft and drilled-in, concrete soldier pile, D is the diameter of shaft. For driven pile, D is the flange width.

Arching can be one of the following values

- Dense sand: arching = 3
 - Medium dense sand and stiff silt: arching = 2*
 - Loose sand, soft silt, and all clay: arching = 1
- * Arching=2 is recommended.

n is a multiplier, which is determined based on pile installation method: driving or drilling

- For driven pile, n=1.5. Generally, driven steel piles have small flange width.
 - For drilled shafts filled with lean concrete or cement, n=1*
- * For drilled shaft filled with gravel, the arching should be reduced based on soil conditions. n=0.5 for clay, and n=0.75 for sand.




7.3 Vertical Bearing Capacity

Vertical loading

Shoring walls experience three types of vertical loading:

- Down drag force from tieback anchors: if the angle of anchor is large, the down drag force will be significant.
- Vertical components from external force
- Vertical components from active pressure: it is assumed that the friction between soil and wall resists the vertical components; therefore, this is ignored in the shoring calculation.
- Vertical loads at the top of wall. Engineers often use the wall as vertical pile to support structural loading.

The total vertical loading transferred to the shaft below the base. If there is not enough bearing capacity, the pile will settle. Therefore, checking the vertical resistance capacity is important for a soldier pile system with many tieback anchors.



$$F.S. = \text{Vertical Capacity} / \text{Vertical Force}$$

Vertical Bearing Capacity Check

Vertical Bearing Capacity

Vertical bearing capacity is determined by three components:

- Tip resistance at pile tip
- Side friction around shaft below base
- Side friction between the pile and soil above the base: it is assumed that only the back face of pile is in contact with the soil.

Users have to input allowable tip-bearing resistance and side friction to let program calculate the capacity. If the capacity is not enough, the program will issue a warning and ask the user to increase pile embedment.

- Sheet piles generally do not have a vertical capacity problem because of the large contact area between the wall and the soil. The friction in the area can resist most of the vertical loading.

- Soldier piles with many tieback anchors need their vertical capacity to be checked due to the large down-drag force and small contact area between the pile and the soil. The friction between lagging and soil cannot be transferred to piles.

The requested embedment to support the vertical loading is calculated and provided by program.

$$\begin{aligned}\text{Tip Resistance} &= (\text{Tip Area}) * (\text{Bearing}) \\ \text{Side Resistance} &= (\text{Side Area}) * (\text{Friction}) \\ \text{Total Vertical Capacity} &= \text{Tip Resistance} + \text{Side Resistance} \\ \text{F.S.} &= \text{Total Vertical Capacity} / \text{Total Vertical Loading.}\end{aligned}$$

Where:

Tip area – area of pile tip

Side area – Surface area of shaft below base and half of surface area above base

Bearing – Soil end bearing (user-input parameter), ksf or kPa

Friction – Friction between soil and shaft (user-input parameter) ksf or kPa

F.S. – Factor of Safety. If F.S. < 1, there is down-drag problem and the pile is passable to settle.

7.4 Embedment Calculation

Users are responsible to have adequate Factor of Safety (F.S.) in embedment based on project condition. There are two ways to apply F.S. in embedment. One is input F.S. in Option page D., Item 15. It will reduce passive pressure by dividing the pressure by F.S. Another way is increasing embedment length or total pile length based on calculated embedment from program.

Cantilever Wall:

The program searches for an embedment to reach moment equilibrium, that the moment is balance at pile tip. For the force equilibrium, there are different approaches in Shoring practices.

1. Some engineers suggest the force equilibrium is satisfied at the same embedment of moment equilibrium. There is no additional increasing of embedment.
2. USS (Steel Sheet Piling Design Manual, Page 23, Simplified Method) suggests the embedment should be increased by 20% to 40% to get the design embedment or so called force equilibrium.
3. AASHTO Standard Specifications suggest, first calculate embedment for moment equilibrium, then add safety factor of 30% for temporary shoring; add safety factor of 50% for permanent shoring. The program provides 20% increasing as in Results graphical pages, and then provides 20%, 30%, 40%, and 50% increasing in Report text pages. The program gives users options to increase embedment based on above approaches (See Program Input Page D, Item 21). Users are responsible to check the project condition to select proper value. The default value is 1.2. Even AASHTO calls the increasing as safety factor, users should not confuse it with Factor of Safety in Input Page B, Item 2, which is an additional FS for passive pressures. Some engineers think the compounding safety factors is unnecessarily conservative and expensive.

Braced Wall:

Based on the last brace, the program searches for an embedment to reach moment equilibrium then determines the brace force based on force equilibrium. Both moment and force equilibriums are satisfied. However, if the calculated embedment is less than eight feet, the program will provide warning “ 5-10 feet is recommended”. In Shoring practice, embedment should be at least 5 feet to prevent unexpected events and accident such as short pile, soft ground, running water, construction error, boiling and heave...etc.

Fixed Embedment:

If there is an existing wall, or the pile length is limited, or an obstruction is encountered below the base, the embedment is fixed and cannot be determined by program. The program gives the option of specifying a fixed embedment.

1. If the software determines that the request embedment is less than the fixed embedment, this required embedment is used regardless of the fixed embedment. If you want to use an embedment, which is deeper than request minimum embedment, you can apply a FS to the passive resistance in Page B, Item 2. Increasing the FS until the calculated request embedment closes to the embedment you want.

- For a system with two or more braces, the program will let the last brace take more loads from passive resistance on pile embedment so that a solution can be reached.
- For a one-brace or cantilever system, the program cannot shift passive resistance to the brace. If this is the case, it will try to calculate a factor of safety of the system with reduced embedment. This is useful for evaluating an existing shoring wall. If the safety factor is low, the system is not safe.

7.5 Limited Penetration in Rock

Quite often, when bedrock is encountered, the pile cannot be driven or drilled into desired depth. Without adequate embedment, the system is not safe. However, there is a solution to this issue if the pile can be driven 2-3 inches into the rock or the drilled shaft has at least one foot of penetration into the rock. Significant friction can

be developed to stabilize the shoring system. In this situation, the user has two options:

- If the penetration into the rock is good, unlimited friction can be developed, and the program will thus be able to determine the friction.
- If the rock is weakened or soft, the penetration may meet the requirements, and users should input the limited friction based on shear strength of rock. Units are in ksf or kpa

Note: This option cannot be used for cantilever walls, and should be limited in a one-braced wall.

7.6 Adding Ms for Embedment Calculation

When {Shoring} calculates the embedment, it takes the moment at the last brace. If it finds a moment equilibrium condition, the search is stopped and the embedment D is determined.


Some designs would like to add an additional pile moment capacity into equation as show in the figure.

In this way, the pile embedment can be reduced. This is especially important for cantilever wall. However, the embedment must be deep enough in the soil to fully develop M_s . Generally, eight feet (2.4 meters) is the minimum requirement. Using M_s is not recommended. If you do not know how to use M_s , Please do not apply M_s .

M_s is for someone with extensive shoring experiences. It needs a lot of engineering experiences and judgment. Improperly using M_s causes failure in shoring. There is no default value for M_s . It is based on the pile you input. If M_s is used and the program finds the embedment is too short, it will ignore or reduce the effects of M_s .

If bedrock is encountered and pile embedment is limited, select [Fixed Embedment Option]. Adequate penetration in rock is required to develop friction as shown in the drawings.


- If it does not meet the requirements, select [No].
- If it is strong rock and meets the requirements, select [Unlimited].
- If it is weak rock and meets the requirements, select [Limited] and input rock strength in the input box.



Driving steel pile requirement:
At least 2-3" penetration in rock

Drilled shaft requirement:
At least 1' penetration in rock

Friction at Pile Tip




$$P_{AI} l_1 - \frac{P_D}{F_S} l_2 - M_S = 0$$

M_S = ALLOWABLE MOMENT IN SHEETING

7.7 Normal Brace Level and Low Brace Level. (This option is removed from program due to the risk of instability)

For normal brace conditions, when program takes the moment at the brace level, the moment for active pressure is clockwise. Moment for passive pressure is counter-clockwise. Therefore, moment equilibrium can be reached.

For low brace conditions, when the software takes the moment at brace level, moment for active pressure is counter-clockwise. Because moment for passive pressure is also counter-clockwise, moment equilibrium cannot be reached. Therefore, passive pressure must be developed on the right side to achieve moment equilibrium. However, this system may not always be stable. **Warning: This option is removed from program due to the risk of instability.**



7.8 Deflection Calculation:

The deflection calculation should be started from pressure diagram.

Pressure Diagram

The pressure diagram is inputted by users or imported from the {EarthPres} module.

Shear Diagram:

The shear diagram is the integration of the pressure diagram.

$$V = \int p \, dz$$

where,

V = Shear force at any point

p = Pressure at any point

dz = Length segment for integration

Moment Diagram

The moment diagram is the integration of the shear diagram. The zero shear location is where the peak moment occurs.

$$M = \int V \, dz$$

where,

M = Moment at any point.

Deflection Diagram

The deflection diagram is the double integration of the moment diagram. The first integration generates a slope diagram, which is not shown in the report. The second integration generates the deflection diagram using the following formulas:

$$\theta = \int (M/EI) \, dz$$
$$y = \int \theta \, dz$$

where,

θ = Slope angle of curve

E = Elastic modulus of pile

I = Moment of inertia of pile

y = Deflection at any point

Note: Both the maximum deflection and the top deflection are given in the deflection diagram. For cantilever walls, the maximum deflection occurs at the top of the wall, and thus equals the top deflection. Boundary conditions are required to define the deflection diagram. In the program, it is assumed that the deflection is zero at the brace level.

The numerical integration above can be found in most structural textbooks. Deflection calculation for shoring walls uses numerical processes. It is difficult to develop a single equation or formula to calculate the deflection of shoring wall.

Numerical Solution

In the program, numerical integration is performed. Assuming the depth is D, which can be divided into N segments. The segment has length dz

For i from 1 to N do integration at each point:

$$Z(i+1) = Z(i) + dz$$

$$V(i+1) = V(i) + p(i) \, dz$$

$$M(i+1) = M(i) + V(i) \, dz$$

$$\theta(i+1) = \theta(i) + M(i) \, dz / EI$$

$$y(i+1) = y(i) + \theta(i) \, dz$$


where:

Z(i) and p(i) are known. So V(i), M(i), $\theta(i)$, and y(i) can be calculated.

Deflection calculation for cantilever case - Point of Fixity.

For cantilever wall, the fixed point is about 1/2 to 2/3 of embedment. The program checks the passive resistance and determines the point fixity. The results have been checked with many field measurements. We found our deflections are a good match with the field measurements. If you get different deflection

from other programs or methods, probably, the main reason is the different assumption of location of point of fixity.



7.9 Pile Strength and Size

When the maximum moment is determined by the {Shoring} module, the required pile section modulus is calculated by the following set of equations:

$$S_m = M_{\max} / F_b$$

Where:

F_b = User inputted ratio * F_y . (Typically User inputted ratio = 0.66)

F_b – Allowable bending strength

F_y – Pile yield strength

M_{\max} – Maximum moment of pile

S_m – Minimum section module

The program can automatically find a list of piles that meet the S_m requirement.


Sometimes, a pile will be designed with multiple sections; each section should meet the bending moment requirement.

Users can check the moment diagram or output data to find the moment distribution along the depth.


7.10 Single Span Beam and Continuous Beam

Users can let the software calculate moment as single span between braces. This will generate a large moment in the middle of span and may be conservative. However, when the shoring is in the construction stage, the pile is occasionally overstressed during over-excavation. This conservative approach can cover this overstressed situation.

In the final stage, users can calculate moment as Continuous Beam between braces. This will reduce maximum moment by about 20%. This approach cannot be used for a cantilever or one brace wall.



Calculate moment as Single Span between braces:
Generate large moment.
This is good for stage construction.



Calculate moment as Continuous Beam between braces:
Reduce Max. moment about 20%.
Not applicable for cantilever or one brace wall.

7.11 Pile Buckling


Generally, design engineers do not consider pile buckling for the following reasons:

Soldier pile is confined by lagging that runs parallel to the wall. In the perpendicular direction, one side is supported by the soil, and braces (struts or tiebacks) support the other side at a certain distance. Sheet pile is also supported by soils and braces. Therefore, the program does not provide buckling calculation. However, if the tiebacks have a large angle and generate large down-drag force, or there is vertical loading at the top of wall, pile buckling should be checked.

7.12 Step Wall Calculation

Warning: CivilTech includes this method as an option. There are no references about this method. Civiltech does not provide any technical support and is not responsible for this method.

The program can analyze step wall through the following steps. The active pressure from wall 1 is passed to passive pressure of wall 1 and translated to wall 2 as additional active pressures.




Step 1. Run Wall 1

- Assuming there is no wall in front of Wall 1 and Wall 2
- Use the {EarthPres} module based on existing soil parameters to find the active and passive pressure
- Use the {Shoring} module to run wall 1 and find pile size and embedment D_1

Step 2. Run Wall 2 and Find the Critical Distance: $X_c = 0.6(H_2 + D_2) + 1.7D_1$

- Assuming there is no wall behind Wall 2
- Run Wall 2 and find D_2 .
- If $X > X_c$, Wall 1 does not have impact on Wall 2, so proceed to design Wall 2 without consideration of Wall 1.
1. If $X < X_c$, Wall 1 may have an impact on Wall 2, so go to Step 3




Step 3. Find total Pressure for Wall 2

Use {EarthPres} to get active pressure $Pa2$ (Based on the adjusted ground surface)

Total pressure $P2$ is a combination of $Pa2$ and part of the passive pressure $Pp1$ from Wall 1: $P2 = Pa2 + (1-X/Xc) * Pp1$

Step 4. Run Wall 2 again

Use {Shoring} to run wall to again and find pile size and final embedment $D2$.




Notes:

- If there are more walls below Wall 2, repeat the same steps for the next lower wall
- Overall stability of the complete wall system should be checked.
- Tiebacks are recommended in order to reduce the embedment of upper walls, thereby reducing impact on the lower walls.
- The bonded length of tiebacks should be placed outside the active and passive zone of the each wall.
- The bonded length of tiebacks should be placed outside the failure plan defined in the stability analysis.
- Surcharge pressure should be applied for each wall using the {Surcharge} module.
- Earthquake load should be applied based on local conditions.
- There is no reference. It has been used among shoring engineers. The method is recommendation only. Engineering judgment is required to use this method.

CHAPTER 8: METHOD FOR THE EARTH PRES MODULE

8.1 Flexible Wall and Rigid Wall

1. Flexible Wall - A wall body is flexible if it allows small movements, such as soldier pile wall and sheet pile wall. Due to the wall movement, the pressure behind the wall is released from the at-rest pressure K_o to active pressure, K_a . For gravity retaining walls, although the wall body is rigid, small rotation is allowed between wall and soil, and thus these walls are also considered flexible. Active pressure should be used for design.



2. Semi-flexible Wall - Walls between flexible and rigid are called semi-flexible walls. Small movement is allowed, but the movement is less than that of the flexible wall. Active pressure, K_a , can be used.

3. Rigid Wall - A typical rigid wall is a basement wall. The wall body is rigid, as the top and bottom of the wall are restricted by the floor and slab. No movement is allowed. The pressure behind the wall is the at-rest K_o condition.

Loading Control Movement - Users can control the wall movement even though wall is flexible. For a flexible wall, if users apply K_o loading to the design to reduce movement, the wall will have less movement. If there are settlement-sensitive structures such as utilities or foundation behind the wall, the users should select the at-rest K_o condition for soil pressure, and select surcharge for rigid walls option for shoring design.

8.2 K_o and K_a Conditions

K_o is the at-rest condition. The soil pressure is higher than K_a . Using K_o implies that the wall cannot have any movement. If there is a settlement-sensitive structure behind flexible wall, or if the wall is rigid, K_o should be used.

$$K_o = 1 - \sin \phi$$

K_a is active condition. This implies that the soil behind the wall allows for small movements. Although it is suitable for most shoring wall design, it should not be used if movement is restricted due to settlement-sensitive structures behind wall.


$$K_a = \tan^2(45 - \phi/2)$$

8.3 Apparent Pressure Envelopes

Peck (1969) suggested using apparent pressure envelopes for shoring design. Apparent pressure envelopes are converted from the total active force calculated from wedge or Coulomb's analysis. For uniform soil, this value is $E_{ae} = 0.5K_a\gamma H^2$. A conversion ratio is involved in the conversion.


$$\text{Conversion ratio} = \text{Total force of envelope} / \text{Total active force above base}$$

Triangular Envelope – For cantilever walls or one wall braced with all types of soil. There is no agreement on one braced wall, some designers only use triangular for cantilever wall. The slope of the pressure equals $K_a \gamma$, which is called equivalent fluid density. The slope may be different from the slope below the excavation base, if you have multiple soil layers. Pressure, $p_a = K_a \gamma H$ at base. The pressure increases with depth, and the total active force (area of envelope) is $0.5 K_a \gamma H^2$. The conversion ratio $= 0.5 K_a \gamma H^2 / 0.5 K_a \gamma H^2 = 1$.



**No Brace or One
Brace Wall
All Types of Soil**

Rectangular Envelope – For two or more brace walls with sand. For walls with two or more braces, the pressure is shifted up due to vertical arching and preloading of braces. For sandy materials, the envelope is rectangular as shown in the second figure. The slope in this case is zero. Pressure, $p_a = 0.65 K_a \gamma H$. The total force (area of envelope) is $0.65 K_a \gamma H^2$, which is 130% of total active force above base. The conversion ratio $= 0.65 K_a \gamma H^2 / 0.5 K_a \gamma H^2 = 1.3$.




**Braced Wall
Majority of Soil is
Sand and Silt**


Trapezoid Envelope 1 – For two or more brace walls with soft to medium clay. For walls with two or more braces in soft to medium clays, the trapezoid envelope is recommended. Pressure, $p_a = K_a \gamma H$. Based on Trapezoid Envelope shape, the total force (area of envelope) is $0.875 K_a \gamma H^2$. The conversion ratio $= 0.875 K_a \gamma H^2 / 0.5 K_a \gamma H^2 = 1.75$.

Trapezoid Envelope 2 – For two or more brace walls with stiff clay. There are two slopes at the top and bottom, at $0.25H$ distance, Pressure, $p_a = 0.8 K_a \gamma H$. Based on Trapezoid Envelope shape, the total force (area of envelope) is $0.6 K_a \gamma H^2$. The conversion ratio $= 0.6 K_a \gamma H^2 / 0.5 K_a \gamma H^2 = 1.2$.



Note: The above ratio is default in program. Users can input own values such as shape (for example, change $0.25H$ to $0.2H$) and ratio in option page.



**Braced Wall
Majority of Soil is
Soft to Medium Clay**



**Braced Wall
Majority of Soil
is
Stiff Clay**



8.4 Method of Earthquake Analysis

For temporary shoring walls within less than a one-year lifetime, it is not necessary to apply earthquake loading. For permanent shoring walls or walls with a life longer than one year, earthquake loading should be considered.

The program applies two additional earthquake forces, $K_h W$ and $K_v W$, in the wedge analysis. W is the weight of the wedge, K_h is horizontal earthquake acceleration coefficient, and K_v is vertical coefficient. A typical value of K_h would be 0.3. This means that the earthquake acceleration is equal to 0.3g. K_v is usually K_h multiplied by 0.5.

In active conditions with single granular soils, the wedge analysis generates results that match up with the results from the Mononobe-Okabe equation. The Mononobe-Okabe equation is shown below:

$$P_{AE} = \frac{1}{2} K_{AE} \gamma (1 - k_v) h^2$$

$$K_{AE} = \frac{\cos^2 (\phi - \psi - \theta)}{\cos \psi \cos^2 \theta \cos (\psi + \theta + \delta) \left[1 + \sqrt{\frac{\sin (\phi + \delta) \sin (\phi - \psi - \beta)}{\cos (\beta - \theta) \cos (\psi + \theta + \delta)}} \right]^2}$$

$$P_{PE} = \frac{1}{\gamma} K_{PE} \gamma (1 - k_v) h^2$$

$$K_{PE} = \frac{\cos^2 (\phi - \psi + \theta)}{\cos \psi \cos^2 \theta \cos (\psi - \theta + \delta) \left[1 - \sqrt{\frac{\sin (\phi - \delta) \sin (\phi - \psi + \beta)}{\cos (\beta - \theta) \cos (\psi - \theta + \delta)}} \right]^2}$$

Reference: [DEPARTMENT OF THE ARMY EC 1110-2-6058 US Army Corps of Engineers](#)

If there are multiple soil layers or cohesion, the Mononobe-Okabe equation will not work; users should take advantage of the wedge analysis.

The program generates an additional trapezoid earthquake pressure diagram above the base, which has a total force of 0.6H from the bottom of the wall. Below the base, the earthquake loading is included in the active and passive pressures. Earthquake loading increases active pressure, but reduces passive pressure.

Generally, earthquake loading should apply to both active and passive pressures. Some designers and regulations only require applying the earthquake loading to active pressures. The program provides the option of only applying earthquake loading to the active pressures. If there is no earthquake loading, the equations above are the same as Coulomb's Method.

8.5 Soil Parameter Screen and Relationship

Because of the wide variations of soil and site conditions, the soil parameters should be determined on the basis of field exploration and laboratory testing. However, for preliminary designs or a lack of data, it is often necessary to presume appropriate soil properties based on limited information. The program provides relationships between each property for shoring analysis. The relations are based on the following table (after Terg and Navdocks)

General Soil Parameters for Sand

Compactness			Very Loose	Loose	Medium	Dense	Very Dense
	Symbol	Unit					
SPT*	N _{SPT}	--	0-4	4-10	10-30	30-50	>50
Relative Density	Dr	%	0-15	15-35	35-65	65-85	85-100
Friction	φ	Deg	<28	28-30	30-36	36-41	>42
Unit Weight							
Moist	γ	pcf	<100	95-125	110-130	110-140	>130
Submerged	γ	pcf	<60	55-65	60-70	65-85	>75

*SPT -- Standard Penetration Test

Reference: Steel Sheet Piling Design Manual, USS, 1975, p.12

General Soil Parameters for Clay

Consistency			Very Soft	Soft	Medium	Stiff	Very Stiff	Hard
	Symbol	Unit						
SPT	N_{SPT}	--	0-2	2-4	4-8	8-16	16-32	>32
UCS*	q_u	pcf	0-500	500-1000	1000-2000	2000-4000	4000-8000	>8000
Shear Strength	C_u	psf	0-250	250-500	500-1000	1000-2000	2000-4000	>4000
Unit Weight Saturated	γ	pcf	<100	100-120	100-130	120-130	120-140	>130

*UCS -- Unconfined Compressive Strength

Reference: Steel Sheet Piling Design Manual, USS, 1975, p.12

8.6 Cohesion in Shoring Analysis

Generally, cohesion is not recommended in shoring design. Field experience indicates that:

- Cohesion is not reliable. A vertical cut can stay for a few days but will collapse after some time
- Tieback in the clay will creep
- If there is a small amount of sandy in the clay, the failure will go through the sand. Therefore, a small amount of sand controls the failure
- When water intrudes on the clay, the strength of the clay will reduce significantly
- The property obtained in the field is undisturbed. During the excavation, the clay will be disturbed. The strength of the clay can be changed significantly
- Based on cohesion calculations, the active pressure can be zero or negative. This, however, is a short phenomenon. The pressure will increase when water intrudes or time-creep occurs

Equivalent Clay


Based on the above reason, we suggest avoiding use cohesion in shoring design. A soil type called Equivalent Clay is provided in Soil Parameter Screen. In this type of soil, cohesion is converted to equivalent friction for shoring design. Users should select this type for clay and silt. The conversion is based on that two soils have the same field strength: N (SPT) value. The conversion: C \rightarrow N, then N \rightarrow Phi. The converted soil only has phi and C=0. C to N and phi to N relations are in above table (USS sheet pile manual page 12, table 2 and 3).

If you still want to use C, manually calculate the pressures and directly input in Shoring Module.

8.7 Earth Pressure Analysis

Wedge Analysis

Active analysis assumes that the wall moves away from the soil mass. The soil starts to fail in a straight line. Wedge analysis tries to find maximum force between all the failure lines. Passive analysis assumes that the wall moves against the soil mass and the soil starts to fail in a straight line. Wedge analysis tries to find the minimum force between all the failure lines. Before computer became available, engineers had to draw lines on paper for the wedge analysis. This is called the Culmann method. Using a computer, the analysis is much easier than before.



Coulomb's Method:

It is a special case of wedge analysis when the soil is made out of granular material and is uniform. The limitations of Coulomb's equation are:


- Slope is infinite and the slope angle must be smaller than friction angle.
- Only for granular material, no cohesion

The equations used for Coulomb's Method are presented in Section 8.4.

Rankine Method

It is also special case for Coulomb's method when surface is flat and there is no wall friction.

Active Pressure Analysis



Passive Pressure Analysis

8.8 Numerical Method vs. Equation Method:

The numerical method is used in the program for wedge analysis and log spiral analysis. Using the numerical method, the user can calculate:

- Complicated surface, subsurface conditions
- Different water tables
- Multiple layers of soil
- Soil with cohesion

The numerical method breaks depth into many small segments and calculates the total active force at each depth. Through deviation operation, the soil pressure is generated. Because of the deviation, the results may generate some errors:


- The soil pressure gradually changes from one soil layer to another. There is no sharp change as in Coulomb's equation. However, it is probably true to the actual soil pressure in the field.
- When pressure slope has significant changes, some spike or noise may show up in the results
- When soil changes from cohesive changes to granule material or vice versa, some errors may occur in the interface of two layers.
- For large cohesion, search may not be able to find the maximum active force or minimum passive force.

If the above situation occurs, the pressure generated by the numerical analysis may look stranger. Therefore, the equation method should be used.

The equation method, such as Coulomb's equation, has limitations, such as:

- Slope should be infinite. The slope angle cannot be larger than the friction angle
- Only for granular materials, no cohesion
- Users should try the equation method first, then the wedge analysis. Log spiral is used only if the wall friction is large.

8.9 Water Table and Seepage



Sheet Piles and Slurry Walls are considered as water cutoff walls. It only allows water to flow below the tip. Soldier piles and secant pile walls allow water flow below the excavation base. There are different categories:

No seepage at wall tip

If the soil is impermeable, such as clay, the water cannot flow freely from one side to another side. A large net pressure is built up at the active side. The pressures of two sides are not equal.

Seepage at wall tip

For the cut off wall, when the wall tip is in permeable granular soil, the water can flow freely from one side to another side. The pressures at the wall tip are equal for both sides as shown in the drawing.

Seepage at depth other than wall tip

For some shoring walls, the cut off depth is not at the pile tip. For example, plate or sheet pile is used as cut off panel between the two soldier piles. The cut off panel does not reach the pile tip, it only reaches to certain depth below the base. Users can input the depth.

Concrete seal at excavation base

The hydraulic pressure will build up below base. The seal should have enough weight to resist the pressure with an appropriate safety factor. Sometimes, sump drain is used to release pressure.


CHAPTER 9: METHOD FOR SURCHARGE MODULE

The function of a retaining structure is to retain various surface loadings as well as the soil behind it. These surface loadings, or surcharges, generate lateral pressures on the wall, which contribute to the active pressures that tend to move the wall outward. Typical surcharge loadings come from railroads, highways, buildings, piles, cranes, etc. The loading cases of particular interest in the determination of lateral soil pressures are described below:

9.1 Strip Loads (Wayne C. Teng Equation)

Highways and railroads are examples of strip loads. When they are parallel to a shoring wall, the lateral pressure distribution on the wall may be calculated using the figure below.


$$\sigma_H = \frac{2Q_s}{\pi} [\beta - \sin \beta \cos 2\alpha]$$



- **The middle dash line in drawing is at central line of the angle, β . Many people think it is at central point of the width $W/2$. It is incorrect, which generates different result.**
- This equation is developed by Dr. Teng published in his paper: "Foundation Design, Wayne C. Teng, Prentice-Hall, Inc., Englewood Cliffs, New Jersey, 1962". It is based on Boussinesq equation and modified by experiment. Boussinesq equation is an elastic solution. Teng equation is considered as plastic solution.
- The equation is widely used in shoring design and is well accepted by shoring engineers.

9.2 Area Loads

Buildings and large equipment are typical area loads. When they are placed near a sheet pile wall, the lateral pressure distribution on the wall can be calculated as shown in the figure below. The lateral pressure due to an area load can be calculated by using integration of Boussinesq equation (Reference: Poulos & Davis, "Elastic Solutions for Soil & Rock Mechanics", Page 54). However, the Boussinesq equation is an elastic solution, which generates a relatively higher lateral pressure. Since soils are plastic materials, we think Teng Equation for strip loading is more suitable for the shoring calculation. Therefore, a length factor is added to Teng Equation for area loading calculation. When the length (L) is infinitely long, the equation is the same as that for strip loading.



$$P_{area} = f * P_{strip}$$

Where f is length factor:

$$f = 1 - 1/(0.25 * L/(X+1) + 1)$$

L - length of area loading; X - Distance to the wall.

When L is infinite, $f = 1$, $P_{area} = P_{strip}$

We plotted curve from Boussinesq equation and use this curve to scale down to fit Wayne C. Teng Equation.
Then we get the above equation.

9.3 Line Loads

A continuous wall footing of narrow width or similar load parallel to the retaining structure may be taken as a line load. In this case, the lateral pressure increases from zero at the ground surface to a maximum value at a given depth and gradually diminishes at greater depths. When the width = 1 (foot or meter), The strip load become line loading.

9.4 Point Loads

The lateral pressure distribution on a vertical wall due to a point load may be calculated as shown in Figure below.

When $L=1$ in Area Loading Equation,

$$f = 1 - 1/(0.25 * 1/(X+1) + 1)$$

$$P_{point} = f * P_{strip}$$

9.5 Infinite Loads

The infinite loading has two options:

1. Conversional active or at-rest method. It is based on active failure analysis. This option 1 is recommended.


$p = K_a q$ as active pressure. It is for flexible wall

$p = K_o q$ as at-rest pressure. It is for rigid wall

$p = (K_a + K_o) q / 2$ It is for semi-rigid wall

2. Strip loading method as described in Section 9.1, where Loading Width = infinite.

This option gives much higher pressure. Because it is originally from an elastic solution, even modified by Dr. Teng.



**E-80 COOPER
RAILROAD LOADING**

9.5 Railroad Loads

The railroad load is for standard E-60 and E-80 Cooper loading. On the figure below, X is calculated as the distance from the wall to the center of the railroad track. The locomotive weights of 520 metric tons and axle loads equal to 37 metric tons (80 kips). The load is acting on two tracks 9 feet apart. The axle spacing is 5 feet. The vertical surcharge is $80/(5' \times 9') = 1.778$ ksf. For standard E-60 and E-80, A rigid wall option is automatically selected in Item 3 of Wall Condition in Input Page A. The calculation equation is the same as the one used in < Section 9.3 Strip loading. Please note: X of Strip loading is from wall to the nearest edge of the strip load. Therefore, if users check it with Strip loading, the $X_{\text{strip}} = X_{\text{rail}} - 9/2 = X_{\text{rail}} - 4.5$. Width = 9. $q = 1.778$ ksf.

The railroad load option of the program assumes 9 feet as railroad ties and use $q = 80/(5' \times 9') = 1.778$ ksf.

If you use 8.5 feet as railroad ties. $q = 80/(5' \times 8.5') = 1.882$ ksf. You need to use strip load option and input $q = 1.882$ ksf.

9.6 Flexible and Rigid Walls

Wayne C. Teng Equation is based on Boussinesq equations, which gives higher pressures due to following reasons:

1. Boussinesq equation is elastic solution. Soil is plastic materials.
2. Boussinesq equation assumes half space condition and ground does not move. But in flexible wall condition the ground moves under lateral pressure. After the movement, the pressures are partially released.
3. Field measurements indicate Boussinesq equation give 50% higher pressures.
4. The shoring design is based on failure analysis. K_a (active coefficient) is used instead K_o (at-rest coefficient).
 K_a is used for determination of the active pressure for flexible wall condition.
 K_o is used for rigid wall condition (at-rest condition).

Commonly, Wayne C. Teng Equation is used for rigid wall condition.

It can be reduced about 50% to match K_a pressure for flexible wall condition.

In the program, the calculated pressure of flexible wall gets 50% of the pressure from rigid wall. The calculated pressure of semi-flexible wall gets 0.75 of the pressure from rigid wall. The 50% deduction for the flexible wall is from shoring practices. **There is no reference. The program provides it only as an option. Users are responsible to use 50% deduction.**

CHAPTER 10: METHOD FOR HEAVE MODULE

Most of the time, heave happens in clay or sandy clay soils. For clay, the method developed by Bjerrum and Eide (1956) can be used; for sandy clay and clay with sand, Terzaghi's method (1943) is suitable. Bjerrum's method only considers cohesion while Terzaghi's method considers both friction and cohesion of the soils. Users should use their own judgment to determine which method is more suitable for situation in the field. In {Heave}, only Terzaghi's method is used.

10.1 Terzaghi's Method

The method of heave analysis was proposed by Terzaghi. The method was used for trench excavation. It also can be used for soldier pile wall. People use this method for sheet pile wall and ignore the resistance from sheet piles.

Both the friction angle and cohesion of the soil are given. It can be seen that the proposed failure is defined by the sliding surface bce.

According to this theory, the factor of safety against heave is

$$\text{Factor of Safety (FS)} = \text{Resistance Force} / \text{Driving Force}$$

Where the driving force is the force that pushes soil block abcd downward. It includes the weight of this block and surcharge on top. This is expressed as:

$$F_{\text{drive}} = W_{\text{abcd}} + q B_1$$

Where:


W_{abcd} is the total weight of abcd

q is the surcharge applied on the surrounding ground surface—ab.

B_1 is the distance of ab.

$$B_1 = B / \sqrt{2}$$

B is the width of excavation.



Resistance force is formed by the friction along the failure line and the bearing capacity of the base soil under dc, which is calculated by Meyerhof's modified bearing equation (Das, 1990).

The resistance force R is calculated using the following formulae:

$$R = q_u B_1 + F$$

$$q_u = (C_b N_c F_{cs}) + (\gamma'_b B_1 N_q F_{rs} / 2)$$

Where:

C_b and γ'_b are the cohesion and the effective unit weight of base soil (Input total weight in program)

N_c and N_q are the bearing capacity factors

F_{cs} and F_{rs} are the shape factors

And F is the friction force along the possible failure plane of bc , which can be expressed as:

$$F = \Sigma(c dz) + \Sigma(Ka Pv \tan \phi dz)$$

Where:

Ka is the Rankin's active coefficient.

Pv is the vertical earth pressure at the middle of each layer.

dz is the thickness of each soil layer.

c is the cohesion of soil.


ϕ is the friction angle of soil.

The Factor of Safety (F.S.) can be determined for the base soil of dc .

$$FS = R / F_{drive}$$

10.2 Hard Stratum

If hard stratum is encountered within the possible failure zone, the failure surface will be terminated at the top of the hard stratum where heave is unable to occur, and will thus increase the overall F.S. The figure below shows this situation for Terzaghi's method.



CHAPTER 11 QUESTIONS & ANSWERS

I cannot change printer

For some Windows operation system, you can't change printer within program.

If you want to change printer, you need to do followings:

1. Close the program.
2. In Windows, click Start; go to Setup, Printers & Devices
3. Select the printer you want, make it default printer. Close the panel.
4. Open the program again. Then send to print.

How to make a PDF file?

You need to install PDF writer such as Adobe PDFwriter (or CurePDF, DoPDF). It is installed in your computer as one of your printers. To print PDF file, you need to do followings:

1. Close the program.
2. In Windows, click Start; go to Setup, Printers & Devices
3. Find the PDF writer you installed before, make it as default printer. Close the panel.
4. Open the program again. Then send to printer. The PDF write will ask you where to save the file. Input the path to save the PDF file.

Input Error

If you are in a country other than US, you may use decimal symbol “,” instead “.”

Our software must use "." for decimal symbol.

You need got to Windows Control panel, Open "Regional and Language Options"

Select Number Tab, change Decimal symbol from “,” to “.”

Buttons in input screen shifted or not aligned

For some computers, the buttons may not be aligned with column in the table. You may do followings to improve it:

1. Go to Windows Control Panel,
2. Open Display,
3. Try different Screen resolutions and Fonts size. Most of time, you can fix the problem.

How the program convert N_{spt} to other soil parameters?

The program used Section 8.5 from N_{spt} to get the other soil parameters.

Does N_{spt} need to be corrected?

Yes. You need to input corrected SPT such as N_1 . If you only have field SPT, it is OK to use them directly, because the conversion is based on statistic data. It is not so accurate.

Under the slide ruler, the N value only up to 60. How to account for $N > 60$.

References only can find correlations between N and ϕ , C , unit weight up to $N=60$, If $N>60$, Users can directly input ϕ , C , and unit weigh based on lab testing or local experiences. Actual, N above 60 does not have too much meaning (SPT method is back 70 year old and very rough). Randomly encountered, large gravel, rock pieces, or cobblestones can increase N significantly. Lab tests such as unconfined compression test provide more meaningful data.

How to apply Load Factors and Factor of Safty?

- In Surcharge module, apply Load Factor in Page A, Item 4.
- In EarthPres module, apply Load Factor in Page E, Item 4-7.
- In Shoring module, apply Load Factor in Page B, Item 1.
- Please note, the Load Factor in Shoring is duplicated with Load Factor in EarthPres. You only apply it in one place. Please do not apply it twice.

- There is also a Factor of Safety in Shoring module in Page B, Item 2. For temporary wall, FS =1 to 1.3 is recommended. For permanent wall, 1.5 is recommended.

How can seismic condition be considered in analysis?

In EarthPres module, input acceleration from local building code. Earthquake pressure is based on Mononobe-Okabe method.

How to handle a force at wall top?

You have two ways to input. 1. Input a force in Page C, Item 5 of Shoring. 2. Apply a pressure equals to the force in Page B, Item 1. For example, Z1=0', Z2=1', P1=1ksf, P2=1ksf, Spacing = 1' (for sheet pile, in Page A, Item 4). It is equal to a force 1 kip per foot. If Spacing = 8' (for soldier pile), the force will be 8 kip for each pile. For a force is toward the wall, input P1, P2 negative value.

How to input Ms (item 12 in Page D, Option page, Shoring)?

Please see Page 7.2-103 of DM7 for Ms. Using Ms is not recommended. If you do not know how to use Ms, Please do not apply Ms. Ms is for someone with extensive shoring experiences. It needs a lot of engineering experiences and judgment. Improperly using Ms causes failure in shoring

How to handle Rock at bottom?

You need to use at least one brace. For cantilever wall, the shoring system is not stable. You can handle the case with two options:

1. Select Option 3 in Item 9, 10, 11 in Page D.

Input a fixed embedment and friction between rock and pile tip.

2. Directly input a large passive resistance for rock layer in Page B, Item 2. Typical value: Z1 -Top of rock, Z2 - bottom of rock, P1=P2 = 3ksf to 5 ksf.

Does the program apply Rowe Reduction?

No Rowe Reduction applied. You can apply it after program gives maximum moment,

If the existing wall has embedment less than program required minimum embedment?

For cantilever wall, the fixed embedment should be longer than the required minimum embedment. Otherwise, the wall is not stable. If the existing wall has been there for a long time, the active pressure inputted may be too large. You can reduce the active pressure by input a factor <1 in Item 1, Page B.

If the wall has embedment more than program required minimum embedment?

If you have fixed embedment longer than required minimum embedment, the program only uses the minimum embedment. Because the program is based on the passive pressure you inputted. you can redistribute the passive pressure by inputting a FS > 1 in Item 2 of Page B. The passive pressure will be redistributed and the embedment increases. Increasing the FS until the calculated minimum embedment = fixed embedment.